451L Cheat Command Cheat Sheet

Mohamad Abou Harb

March 12, 2021

Contents

1	Changing Device IP's:	2
2	Displaying routing tables for devices	3
3	Adding/Deleting Routes to Devices	4
	3.1 Clearing ip routes for devices	4
4	Adding rip protocols on devices	5
	4.1 Routers	5
	4.2 PCs	5

1 Changing Device IP's:

• pc: sudo ifconfig eth0 'ip' netmask 'netmask'
ex: sudo ifconfig eth0 10.42.1.10 netmask 255.255.255.0

• router: configure terminal

router[config]: interface FastEthernet0/0

router[config]: ip address 'ip' 'netmask'

router[config]: no shutdown

router[config]: end

2 Displaying routing tables for devices

• pc: netstat -rn

• router: show ip route

3 Adding/Deleting Routes to Devices

• pc: sudo route add -net 10.42.1.10 netmask 255.255.255.0 gw 10.42.3.4 pc: sudo route del -net 10.42.1.10 netmask 255.255.255.0 gw 10.42.3.4

• pc: route add default gw 10.42.3.4 pc: route del default gw 10.42.3.4

• router[config]: ip route 10.42.1.10 255.255.255.0 10.42.3.1

3.1 Clearing ip routes for devices

• pc: sudo ifconfig eth0 down

pc: sudo if config eth0 up

This command flushes the routing table on the pc.

• router: clear ip route *

4 Adding rip protocols on devices

4.1 Routers

```
• R1(config) router rip
```

R1(config) version 2

R1(config) network 10.0.0.0

R1(config): end

R1: clear ip route *

4.2 PCs

 \bullet telnet localhost 2602

password is quagga

PC1¿ enable

PC1(config-router): router rip

PC1(config-router): version 2

PC1(config-router): network 10.0.0.0/8

PC1(config-router): passive-interace eht0

PC1(config-router):end